

# MODELS GGX

# QUICK GUIDE




Download manual at:  
[www.greaseguardian.com/product-manuals](http://www.greaseguardian.com/product-manuals)

WARNING




WEIGHT  
OVER 20kg



# Installation Checks




- 1** Ensure basket can be easily removed
  - 2** Allow access to internal parts
  - 3** Ensure gravity flow into unit
  - 4** Ensure gravity flow away from unit has a 1:40 fall and sufficient pipe ventilation
  - 5** Allow access to grease container
  - 6** Allow access to control panel
  - 7** Adjust Programme (or set to default medium cycle which is x 2 per day, 7 days)
-  Fill with water before switching on



For full settings go to:  
[www.greaseguardian.com/product-manuals](http://www.greaseguardian.com/product-manuals)

# Daily Maintenance



- A** Remove cover A, and take out basket B
- C** Remove collection container, empty and replace
- D** Remove wiper blade assembly D, inspect and clean
- E** If connected, spray bar E is available for periodic cleaning (check local plumbing codes).  
Can be operated manually or automatically depending on the option selected

# Getting Started



Download Instructions at:  
[www.greaseguardian.com/product-manuals](http://www.greaseguardian.com/product-manuals)



Ensure unit is plumbed in correctly



Ensure sufficient ventilation of the outlet pipe



Ensure unit is filled with water



Connect to waterproof electrical supply



Ensure power is on (at wall)



Set time and programme. Download Instructions at:  
[www.greaseguardian.com/product-manuals](http://www.greaseguardian.com/product-manuals)



Note all maintenance requirements

Register warranty online at  
[www.greaseguardian.com/register-my-product](http://www.greaseguardian.com/register-my-product)



To download full manual scan here



Full manual available online:  
[www.greaseguardian.com/product-manuals](http://www.greaseguardian.com/product-manuals)



BS EN ISO 9001:2008

