Maintenance Guide

D SERIES

Daily and Regular Maintenance Guidelines for GGD Grease Guardian® Automatic Grease Removal Devices.

DAILY MAINTENANCE

1

EMPTY FOOD WASTE

Lift lid and remove the food waste basket. Dispose of contents into a food waste bin. Wash the basket thoroughly using hot, soapy water.

2

CLEAN WIPER BLADE

Unhook the wiper blade, wipe off any residue with a paper towel, then wash it with hot, soapy water.

3

EMPTY COLLECTION CONTAINER

Pour the collected grease into a waste oil container for proper disposal or recycling.

REGULAR MAINTENANCE

1

FLUSH THE UNIT

1 - 3 TIMES PER WEEK

Fill the sink with hot, soapy water and allow it to flow through the unit. This helps break down any buildup and keeps internal components clean.

2



TANK PUMP OUT

EVERY 3 MONTHS

A full tank pump-out should be carried out by your service partner to ensure continued optimal performance.

Maintenance Guide

X SERIES

Daily and Regular Maintenance Guidelines for GGX Grease Guardian® Automatic Grease Removal Devices.

DAILY MAINTENANCE

1

EMPTY FOOD WASTE

Remove the food waste basket and dispose of contents into a food waste bin. Wash the basket thoroughly using hot, soapy water

2

CLEAN WIPER BLADE

Unhook the wiper blade, wipe off any residue with a paper towel, then wash it with hot, soapy water.

3

EMPTY COLLECTION CONTAINER

Pour the collected grease into a waste oil container for proper disposal or recycling.

REGULAR MAINTENANCE

1

FLUSH THE UNIT

1 - 3 TIMES PER WEEK

Fill the sink with hot, soapy water and allow it to flow through the unit. This helps break down any buildup and keeps internal components clean.

2



TANK PUMP OUT

EVERY 3 MONTHS

A full tank pump-out should be carried out by your service partner to ensure continued optimal performance.